



Thank you for purchasing our product. Please, read the instructions thoroughly and retain them for future reference.

⚠ NOTICE

- To install, follow the steps as described in the manual. Any damages caused by not following directions voids warranty.
- Correct tools must be used for installation.
- Do not modify any parts unless specifically stated in the instruction manual.
- Interior control maintenance should be performed by a professional only.

Ⓞ MARK MEANING:

NOTE You could get the installation details from the information behind the mark.

⚠ Some processes must be followed to avoid the affection caused by wrong installation.

⚠ WARNING! Some processes must be followed to avoid damages to yourself or the public.

⚠ CAUTION! Some processes must be followed to avoid the damage to the vehicle.

Denotes the tightening torque value

1 ACCESSORIES

1 Drive Pulley x1	2 Drive Face x1	3 Drive Cam x1	4 Slider x3
5 Roller 16g x6	6 Torque Spring 1000RPM X1	7 Washer 1mm x1	8 Washer 0.5mm x1

NOTE Please contact the local distributor if the items you open are not the same, as the above-listed one.

2 INSTALLATION INSTRUCTION

1 59Nm (590kgf.cm)

11 49Nm (490kgf.cm)

1 54Nm (540kgf.cm)

NOTE Please do according to figure in order. Make sure to disassemble the parts in reverse order. Please refer to the above picture for installation sequence.