





• Thank you for purchasing the our product. Before installing, please read the instruction carefully and keep it for future re ference.

⚠ NOTICE

- •To install, follow the steps as described in the manual. Any damages caused by not following directions voids warranty.
- Correct tools must be used for installation.
- Do not modify any parts unless specifically stated in the instruction manual.
- •Interior controller maintenance should be performed by a professional only.
- SYMBOL NOTE:

NOTE Read this information carefully regarding the essential features.

⚠ CAUTION! Some processes must be followed to avoid the damage to the vehicle.

To smear grease before installation.

Denotes the tightening torque value.

1-1 ACCESSORY






NOTE Please contact your local distributor if the items received are not the same as the one listed above.

1-2 OPTIONAL ACCESSORIES













NOTE STD 45°





NOTE Some of these items may not sell in particular area, for more information, please contact with our local dealer.

2 GROOVE ANGLE INSTRUCTION



NOTE Straight groove 48°→Softer shifting characteristics-close to the original


3 GEAR RATIO

	KOSO	STD	
GEAR RATIO	3.7	3.2	
NOTE colle	ocation KOSO cygni	us gryphus transmis	ssion power


4 SECONDARY SLIDING SHEAVE WEIGHT

	KOSO	STD
WEIGHT (g)	1045 g	1340g

5 INSTALLATION INSTRUCTION



6 SECONDARY SLIDING SHEAVE INSTALLATION INSTRUCTION



wh073fp103-A-23D

7 POWER CURVE COMPARE CHART

